

This manual provides installation and operating instructions for the AdvantagePB Virtue Shocker/Nerve Upgrade Board.

## Features:

- **7 Modes of fire** - Semi Auto, Modified PSP/NXL, NXL Style Full Auto, Ramp Mode, Auto Response, Full Auto, and Breakout Mode.
- **15BPS Ready** - Be ready for any tournament series! Put Dipswitch 1 in the off position, and your maximum rate of fire is capped at 15bps!
- **All firing modes have user adjustable maximum rates of fire from 10.50bps to unlimited rates of fire!**
- AdvantagePB Trigger Logic constantly monitors the trigger to ensure every trigger pull is recognized, giving you the fastest responding gun, and highest possible rates of fire.
- Adjustable Debounce, Dwell, Anti-Mechanical Bounce (AMB), Eye Sensitivity, Ramp Activation Speed, Ramp Percentage, and Anti-Bolt Stick (ABS).
- Power Efficient Software extends the life of your battery.
- All settings are stored in non-volatile memory so they will not be lost when the battery dies or is removed.
- 10 minute idle auto-shutdown saves battery life.
- Forced Shot allows the marker to be fired when the eyes are enabled, but no object is in the breech.
- Instant On allows the marker to be fired instantly upon turn on.
- Tournament Lock/Unlock allows the marker to be programmed through the trigger without having to constantly open the grip. With the tournament lock enabled, settings cannot be changed without opening up the grip.

## Installing Your AdvantagePB Shocker/Nerve Board:

1. With the grip frame open, push out the two pins that are holding in your existing board.
2. Remove the battery from the wiring harness being careful not to damage the wires.
3. Carefully remove your existing board from the marker and disconnect the wire harness from your existing board.
4. Connect that same wire harness to the AdvantagePB Virtue Shocker/Nerve Board.
5. Place the Virtue Shocker/Nerve board back into the grip frame making sure the bottom of the board is in the slot of the grip frame.
6. Line up the two pins you removed in step 1, and push them back into place.
7. Last, reconnect the battery and close the grips.

## Setting the Dipswitches:

On the AdvantagePB Shocker/Nerve Board, there is a 2-position dipswitch.

Dipswitch 1 is the **Max Rate of Fire/15bps Cap lock**. If Dipswitch 1 is in the on position, your max rate of fire is set to your “Max Rate of Fire” setting (Flashing Red LED in programming mode.) **If dipswitch 1 is in the off position, the Max Rate of Fire of all modes is capped at 15bps.** After changing this setting, you must turn the marker off before it takes effect.

\*Please note the actual bps will vary slightly from gun to gun. If the desired bps is too high or too low with dipswitch 1 off, then leave Dipswitch 1 in the on position, and adjust the max rate of fire setting through the programming menu.

Dipswitch 2 is the **Tournament Lock**. To access the programming mode of the Virtue Shocker/Nerve Board, Dipswitch 2 must be in the on position. **Then hold down the trigger and turn the marker on to enter programming mode.** When Dipswitch 2 is in the off position, the gun is in “Tournament Lock”, and program settings cannot be changed.

## LED Indicator:

The power button on the back of the marker also functions as a small blue LED, telling you the status of your marker:

Solid Blue	Eye Enabled / Ball in Breech
Flickering Blue	Eye Enabled / No Ball in Breech
Fast Flashing Blue	Eye Disabled
Flashing Blue	Eye Malfunction

In addition, the multi-color led on the board will also tell you the status of your gun:

Solid Blue	Eye Enabled / Ball in Breech
Solid Red	Eye Enabled / No Ball in Breech
Flashing Red	Eyes Disabled
Flashing Blue	Eye Malfunction

If you do not wish to use the multicolor LED during play, it can be turned off through the programming menu.

## Power Operation:

The Virtue Shocker/Nerve Board uses Instant On technology. Simply tap the power button, and the marker instantly turns on and is ready to fire. When the marker is turned on, the eye is automatically enabled. To turn the marker off at any time, press the power button for 2 seconds.

## Eye Operation:

When the marker is turned on the eye system is automatically enabled. The eyes can be turned off by pressing the power button for 1 second. When the eyes are disabled the max rate of fire will not go over 20bps.

The eye logic differentiates between a ball being fired, and something continually blocking the eye (like your finger). If the eye becomes blocked, both LED's (if enabled) will flash blue, indicating an eye malfunction. When the object blocking the eyes is removed the eye will automatically return to working mode.

## Programming Mode:

To access the programming mode of the Virtue Shocker/Nerve Board Dipswitch 2 must be in the on position. When Dipswitch 2 is in the off position, the gun is in “Tournament Lock”, and program settings cannot be changed.

With Dipswitch 2 in the on position, hold the trigger and turn the marker on. The multi color LED on the board will then cycle through a rainbow of colors and stop on blue, indicating that you are now in programming mode.

The small blue LED on the back of the gun will also indicate going into programming mode by flashing and flickering blue, then stopping on blue. When adjusting the mode of fire, the small blue LED can be used. This is very useful for changing firing modes on the fly. To adjust any other setting, you must use the multicolor LED, as the small blue LED will go out.

Tapping the trigger will then toggle through the different programming modes:

Blue:	Firing Mode
Green:	Debounce
Red:	Ramp Activation Speed
Flickering Blue:	Ramp Percentage
Flickering Green:	Dwell
Flickering Red:	Eye Sensitivity
Flashing Blue:	AMB (Anti-Mechanical Bounce)
Flashing Green	ABS (Anti-Bolt Stick)
Flashing Red:	Max Rate of Fire
Purple:	LED Options

## To Change the Value of a Setting:

When the LED is lit for the desired setting, pull and hold the trigger until the LED Begins to flash. The LED will flash the number of times the current value is set to. When the LED stops flashing you then have 2 seconds to enter in the new value by tapping the trigger the amount of times you want the new value to be set to. After you have set the new value, the LED will flash back at you the number of times you have just entered, and then flash through the rainbow of colors, returning to the color you have just adjusted, indicating that the new value has been set. To exit programming mode, shut the marker off.

## Programming Example:

If you want to change the debounce to 2 you would:

1. With the marker off, and Dipswitch 2 in the on position, hold the trigger and turn the marker on.
2. The multi-color LED will now cycle through a rainbow of colors and stop on Blue.
3. Tap the trigger once so the LED glows green.
4. Pull and hold the trigger until the LED starts to flash (factory default for debounce is 5, so the LED will flash 5 times).
5. When the LED stops flashing, quickly tap the trigger 2 times.
6. The LED will now flash 2 times, and then flash through the rainbow of colors, and stop on green, indicating the new value has been set.
7. To exit program mode, shut the marker off.

## Reset to Factory Default:

To return all settings to the factory defaults, while in programming mode, hold the trigger down for 10 seconds until the LED turns blue. After the LED turns blue, it will then flash through the rainbow of colors indicating that all settings have been returned to the factory default.

## Adjustable Settings:

### Firing Mode (Blue) Values 1-7 (Default is 1)

- Semi Auto-** Semi Automatic Fire; 1 trigger pull equals 1 shot.
- PSP Ramping-** The first 3 shots of a string are Semi Auto. After the 4<sup>th</sup> shot the marker will ramp to the rate of fire your “Max Rate of Fire” is set to. Once the trigger is let go and 1 second elapses, the 3 shot Semi Auto count restarts.
- NXL Style Full Auto-** The first 3 shots of a string are Semi Auto. On the 4th shot you can then hold down the trigger, and the marker will shoot full auto at your Max Rate of Fire. Once the trigger is let go and 1 second elapses, the 3 shot Semi Auto count restarts.
- Ramp Mode-** When you reach the “Ramp Activation Speed” the Marker will ramp the rate of fire by your “Ramp Percentage” setting, up to your Max Rate of Fire. Factory default is when your trigger speed reaches 5bps, the marker will ramp up to the maximum speed that your loader can feed.
- Auto Response-** 1 shot on the pull of the trigger; 1 shot on the release. This setting will make you shoot twice as fast as you can pull the trigger.
- Full Auto-** Hold down the trigger, and the marker will fire at your max rate of fire, or as fast as your loader can feed.
- Breakout Mode-** In this mode, when you turn the gun on, the first shot will shoot full auto for as long as you hold down the trigger. Once you release the trigger the gun goes into “Ramp Mode”. If you turn your marker off and back on when in this mode, the Breakout function will repeat.

### Debounce (Green) Values 1-30 (Default is 5)

Debounce is the amount of time that the trigger has to be released before the next trigger pull is allowed. Virtue software incorporates our own AdvantagePB debounce algorithm, which ensures every trigger pull is recognized. This results in giving the user the highest rates of fire possible. The values range from 1-50 with the default set to 5.

### Ramp Activation Speed (Red) Values 5-15 (Default is 5)

The ramp activation speed setting only affects Firing modes 4 and 7 (Ramp and Breakout Mode). The default setting is 5, which means when the user reaches trigger speeds of 5bps, ramping will activate, and add the percentage set in the “Ramp Percentage” setting. The values of this setting are equivalent to balls per second. For example, 5 = 5bps; 10 = 10bps, etc.

### Ramp Percentage (Flickering Blue) Values 1- 21 (Default 1)

The ramp percentage setting only affects Firing modes 4 and 7 (Ramp and Breakout Mode). The default setting is 1, which “Maxes Your Loader” as soon as the Ramp Activation Speed is reached.

Value	Percentage	Value	Percentage	Value	Percentage
1	Max Loader	8	40%	15	75%
2	10%	9	45%	16	80%
3	15%	10	50%	17	85%
4	20%	11	55%	18	90%
5	25%	12	60%	19	95%
6	30%	13	65%	20	100%
7	35%	14	70%	21	200%

### Dwell (Flickering Green) Values 5-30 (Default is 12)

Dwell is the amount of time that the solenoid will be activated. The default is 12 milliseconds (ms), and the values range from 5 – 30 ms. Too low of a dwell setting will lead to inconsistent velocities and drop off. Too high of a dwell will result in poor air efficiency.

### Eye Sensitivity (Flickering Red) Values 1-50 (Default is 5)

The Eye Sensitivity setting adds a small delay after the eye has seen a ball before it allows the marker to shoot. Players using non-force fed loaders may need to raise this setting to prevent chopping. The default setting is 5, with 1 being the fastest (No delay).

### AMB (Flashing Blue) Values 1-10 (Default is 3)

The Anti-Mechanical Bounce (AMB) feature allows the user to adjust for mechanical bounce. Mechanical bounce happens when the “kick” from having a shot fired causes the marker to shoot additional shots after the trigger has been pulled. The default setting is 3, which is a low AMB. This setting ranges from 1-10 with 1 being AMB off.

### ABS (Flashing Green) Values 1 –20 (Default is 10)

The Anti-Bolt Stick (ABS) setting is the amount of dwell time added for an ABS shot. This setting ranges from 1 – 20 additional milliseconds of dwell, with the default set to 10.

### Max Rate of Fire (Flashing Red) Values 1-22 (Default 1)

The max rate of fire setting applies to all modes of fire. If Dipswitch 1 is in the up or on position, the max rate of fire is determined by this setting. If Dipswitch 1 is in the down or off position, the rate of fire is capped at 15bps for all modes of fire. The max rate of fire is adjustable from 10.5bps to unlimited rates of fire. The default setting is 1, which is an unlimited rate of fire.

Value	BPS	Value	BPS	Value	BPS
1	Unlimited	10	14.50	19	19.00
2	10.50	11	15.00	20	20.00
3	11.00	12	15.50	21	21.00
4	11.50	13	16.00	22	22.00
5	12.00	14	16.50		
6	12.50	15	17.00		
7	13.00	16	17.50		
8	13.50	17	18.00		
9	14.00	18	18.50		

### LED Options (Purple) Values 1-3 (Default is 1)

The LED Options setting allows the user to choose if the multi-color LED on the board is active outside of the programming menu. In addition, it allows users to only use the multi-color LED if desired, making the small blue LED simply a power button. The default setting is 1, which uses both LED's. If you do not wish to use the Multicolor LED, you should shut it off to conserve battery life.

Value	LED Options
1	Both LED's
2	Small Blue LED Only
3	Multi-color LED Only

For More Information Please See:

[www.AdvantagePB.com](http://www.AdvantagePB.com)

103 Fulton Blvd.  
Commack, NY 11725

*Specifications subject to change without notice.*

**AdvantagePB LLC**

**Virtue**

## Shocker/Nerve Board User's Manual