

Blackmaxx, Tracer, Rampage Retrofit Guide

FIGURE 1

All of the markers in figure #1 have the external retrofit device installed as shown circled in blue below. These markers are ready to use!



FIGURE 2

All of the markers in figure #2 do not have the external retrofit device installed. However you must check to see if they have the new factory installed safety release device as shown in figure #3 & 4 before playing with this marker!



FIGURE 3 & 4

The marker shown in figure #3 & 4 has the new factory installed safety release device. This marker is ready to use.

If your marker does not have the factory installed safety release device or the external retrofit device you must call or e-mail PMI to arrange for your free retrofit service. Call PMI toll free at 800-579-1633 or e-mail at info@pminetwork.com for further details regarding returning your marker for this free upgrade. Do not use the marker prior to calling PMI.

