

| ID          | Name                             |
|-------------|----------------------------------|
| <b>M22</b>  | <b>WG47</b>                      |
| M2201       | WG47 Receiver                    |
| M2202       | WG47 Body                        |
| M2203       | WG47 Body Cover                  |
| M2204       | WG47 Hand-Guard (U)              |
| M2205       | WG47 Hand-Guard (D)              |
| M2206R      | WG47 H.G. Retainer               |
| M2206L      | WG47 H.G. Retainer               |
| M2207       | Rear Windage/Elevation Sight Set |
| M2208       | WG47 Front Sight                 |
| M2209       | WG47 Muzzle Break                |
| M2210R      | WG47 Magazine R                  |
| M2210L      | WG47 Magazine L                  |
| M2211       | WG47 Fix Stock                   |
| M2212       | WG47 Fix Stock Base              |
| M2213       | WG47 Body Base                   |
| M2214       | WG47 Handle                      |
| M2215       | WG47 Handle Base                 |
| M2216       | WG47 Safe Handle                 |
| M2217       | WG47 Rear Sling Ring             |
| M2218       | WG47 Rear Sling Ring Cover       |
| M2219       | WG47 Front Sling Ring            |
| M2220       | WG47 Mag Cover                   |
| <b>M23</b>  | <b>WG47s</b>                     |
| M2301       | WG47 Folding Stock Set           |
| <b>P001</b> | <b>Screw</b>                     |
| P00105      | 3 x 4 Screw                      |
| P00106      | 3 x 6 Screw                      |
| P00107      | 1/8 x 12 Wood Screw              |
| P00108      | 4 x 3 Screw                      |
| <b>P002</b> | <b>Screw</b>                     |
| P00205      | 4 x 8 Screw                      |
| P00206      | 3 x 10 Screw                     |
| P00207      | 6 x 10 Screw                     |
| P00209      | 3 x 20 Screw                     |
| P00210      | M3                               |
| P00211      | 3 x 8 Screw                      |
| P00212      | 5 x 16 Screw                     |
| P00213      | 3 x 4 Screw                      |
| P00214      | 8 x 16 Screw                     |
| <b>P003</b> | <b>Screw</b>                     |
| P00301      | 5 x 12 Screw                     |
| P00303      | 4 x 25 Screw                     |
| P00304      | 5 x 6 Screw                      |
| P00305      | 3 x 8 Screw                      |
| P00306      | 5 x 8 Screw                      |
| P00307      | 3 x 6 Screw                      |
| <b>P004</b> | <b>Hex Retainer Lug</b>          |
| P00401      | 3 x 8 Hex Retainer Lug           |
| <b>P005</b> | <b>Spring</b>                    |
| P00508      | SEAR Spring                      |
| P00510      | Trigger Spring                   |
| P00511      | Trigger tension recoil spring    |
| P00514      | WG47 Hammer Spring               |
| P00515      | WG47 Cocking Spring              |
| P00516      | WG47 Cup Seal Spring             |
| P00517      | WG47 Folding Stock Spring        |
| <b>P006</b> | <b>PIN</b>                       |
| P00604      | ZEUS / WG47 Valve PIN            |
| P00605      | Trigger retaining pin            |
| P00608      | WG47 Front sight retainer Pin    |
| P00609      | WG47 Trigger Guard retainer Pin  |
| P00610      | WG47 Folding Stock retainer Pin  |
| <b>P007</b> | <b>C-clips</b>                   |
| P00701      | 2.5 C-clips                      |
| <b>P008</b> | <b>O Ring</b>                    |
| P00801      | 3x1.5 O Ring                     |
| P00802      | 5.8x1.9 O Ring                   |
| P00803      | 6.07x1.78 O Ring                 |
| P00804      | 12x1.5 O Ring                    |
| P00805      | 14x1.78 O Ring                   |
| P00806      | 14x1.78 O Ring                   |
| P00807      | 15x2.5 O Ring                    |
| P00808      | RIS Handle O Ring                |

|             |                                      |
|-------------|--------------------------------------|
| <b>P009</b> | <b>VALVE</b>                         |
| P00901      | ZEUS / WG47 Valve                    |
| <b>P010</b> | <b>Rubber Parts</b>                  |
| P01002      | ZEUS / WG47 Striker Rubber Buffer    |
| <b>P011</b> | <b>Hammer</b>                        |
| P01106      | WG47 Hammer                          |
| <b>P012</b> | <b>Cup Seal</b>                      |
| P01201      | Cup Seal                             |
| <b>P014</b> | <b>Ball Detent</b>                   |
| <b>P015</b> | <b>Washer</b>                        |
| P01501      | Washer                               |
| <b>P016</b> | <b>Striker Spring Tension Guide</b>  |
| P01601      | WG47 Striker Spring Tension Guide    |
| <b>P018</b> | <b>Bolt / Striker Connection Rod</b> |
| P01804      | WG47 Connection Rod                  |
| P01805      | WG47 Side Connection Rod             |
| <b>P019</b> | <b>Quick Strip Pin</b>               |
| P01902      | WG47 Stock Pin                       |
| P01903      | WG47 Rear Sight Pin                  |
| <b>P020</b> | <b>Bolt</b>                          |
| P02005      | WG47 Bolt                            |
| <b>P021</b> | <b>Striker Rear Cap</b>              |
| P02103      | WG47 Striker Rear Cap                |
| <b>P022</b> | <b>Velocity Adjuster</b>             |
| P02204      | WG47 Velocity Adjuster               |
| <b>P023</b> | <b>Valve Copper Retainer Screw</b>   |
| P02301      | Valve Copper Retainer Screw          |
| <b>P026</b> | <b>Cup Seal Guide</b>                |
| P02601      | For ZEUS, WG47                       |
| <b>P027</b> | <b>ASA Adaptor</b>                   |
| P02704      | WG47 ASA Adapter Set                 |
| P02705      | WG47 Bottom line ASA Adapter         |
| <b>P028</b> | <b>Macroline Airhose</b>             |
| P02802      | WG47 Macroline Airhose               |
| <b>P029</b> | <b>Vertical Power Feed</b>           |
| P02901      | WSF / WG47 Power Feed Body           |
| P02903      | WG47 Power Feed Base                 |
| P02904      | WG47 Power Feed Plug                 |
| <b>P031</b> | <b>Volumizer Plug</b>                |
| P03102      | WG47 Volumizer Plug                  |
| <b>P032</b> | <b>WG47 Cocking Set</b>              |
| P03201      | Cocking Handle                       |
| P03202      | Cocking Handle Guide                 |
| <b>A03</b>  | <b>ASM</b>                           |
| A0303       | SEAR                                 |
| A0304       | Single Trigger                       |
| A0308       | Trigger Back                         |
| A0311       | WG47 Trigger Guard Set               |
| A0312       | WG47 Safe Pin                        |
| A0313       | WG47 Safe Pin Spring                 |
| A0314       | WG47 Safe Pin Cover                  |
| A0315       | WG47 ASM Body                        |
| <b>A08</b>  | <b>Barrel</b>                        |
| A0802       | 16" WG47 Barrel                      |