

● **DRALLION INSTRUCTIONS**

- **USE HPA COMPRESSED AIR ONLY CO2 WILL DAMAGE 5 WAY VALVE**
- **COCK GUN BEFORE ADDING AIR SUPPLY OR GUN WILL LEAK**
- **HOLD LOWER BUTTON FOR 5 SECONDS TO TURN ON .SAME TO TURN OFF**
- **UPPER BUTTON ADJUST MODES**
- **DO NOT ADJUST DWELL UNLESS SHOOTING ABOVE 15 BPS recommend SHOOTING AT THIS SETTING WILL NEED TO CHANGE COCKING SPRING AND DWELL TO SHOOT FASTER**
- **ANY TIME MAIN REG PRESSURE ADJUSTED LOW PRESSURE REG MUST BE SET TOO**
-
- **ADJUST MAIN REG TO 350 PSI NO MORE THAN 500 PSI LARGE ALLEN FITTING ON FRONT GRIP REG .WARNING TO NOT TRY AND ADJUST SMALLER FITTING WILL CAUSE LEAK THIS IS LOCK TIGHTED IN PLACE**
-
- **IF 5 WAYS IS LEAKING OR LINES POP OFF. FRONT REG PSI TO HIGH ADJUST ALLEN WRENCH AT END OF REG COUNTER CLOCKWISE TILL 5 WAY STOPS LEAKING OR BETTER YET TILL GUN WON" T RECOCK THAN ADD ADJUST TILL GUN IS just ABLE TO RECOCK AND ¼ TURN MORE**
-
- **IF GUN DOES NOT RECOCK FRONT REG ADJUSTMENT TO LOW TURN ALLEN FITTING CLOCKWISE ON REG UNTIL COCKS**
-
- **TO SET VELOCITY REMOVE REAR COCKING ROD INSERT LARGE ALLEN WRENCH THRU HOLE AND TURN IN .PUT BACK COCKING ROD AND RECHECK AND ADJUST AS REQUIRED**
- **SET BOLT COCK GUN PULL BACK BLOCK BACK AGAINST COCKING ROD LOOK DOWN IN FEED NECK BOLT SHOULD BE FLUSH WITH BACK OF FEED TUBE .IF NOT LOOSEN COCKING ROD AND ADJUST**
-
- **SEAR ADJUSTMENT IS DONE THRU HOLE TOP OF GUN >REMOVE BOLT INSERT ALLEN WRENCH THRU HOLE AND ADJUST AS NEEDED**
-

NOTE IT IS VERY COMMON FOR AUTOCOCKING GUNS TO NEED THESE ADJUSTMENTS AT TIMES and for leaks to develop when adjustments are off.ABOVE INFO SHOULD FIX ANY PROBLEM ON GUN BUT IF NON OF ABOVE WORKS .ALSO RECOMEND REPLACING VALVE WITH A GOOD LOW PRESSURE ONE AND DELRIN BOLT GUN WILL SHOOT GOOD STOCK AT 12 to 15 BPS WILL REQUIRE ABOVE UPGRADES AND FINE TUNING CALL 215-493-4819

EXPLODED DIAGRAM OF DRALLION

