

ID	Name
M01	ZEUS G1+
M0101	G1+ Receiver
M0102	G1+ Air Cover
M04	ZEUS G2+
M0401	G2+ Receiver
M0402	G2+ Sight Rail
M0403	G2+ Short Barrel
M0404	G2+ Long Barrel
P001	Screw
P00101	4 x 8 Screw
P00102	4 x 12 Screw
P00103	4 x 18 Screw
P002	Screw
P00201	3 x 6 Screw
P00202	4 x 10 Screw
P00203	4 x 12 Screw
P003	Screw
P00301	5 x 12 Screw
P00302	5 x 14 Screw
P004	Hex Retainer Lug
P00401	3 x 8 Hex Retainer Lug
P00402	4 x 8 Hex Retainer Lug
P005	Spring
P00501	ZEUS Hammer Spring
P00504	ZEUS MAG Main Spring
P00505	MAG Housing Spring
P00506	ZEUS Cup Seal Spring
P00508	SEAR Spring
P00509	Safe Spring
P00510	Trigger Spring
P00511	Trigger tension recoil spring
P006	PIN
P00601	3 ∅ PIN
P00602	4 ∅ PIN
P00603	Clip Retainer Pin (Front)
P00604	Valve PIN
P00605	Trigger retaining pin
P00606	Clip Retainer Pin (Rear)
P007	C-clips
P00701	2.5 C-clips
P008	O Ring
P00801	3x1.5 O Ring
P00802	5.8x1.9 O Ring
P00803	6.07x1.78 O Ring
P00804	12x1.5 O Ring
P00805	14x1.78 O Ring
P00806	14x1.78 O Ring
P00807	15x2.5 O Ring
P009	VALVE
P00901	ZEUS Valve
P010	Rubber Parts
P01001	ZEUS Side Rubber Cover
P01002	ZEUS Striker Rubber Buffer
P011	Hammer
P01101	ZEUS Hammer
P012	Cup Seal
P01201	Cup Seal
P01202	Cup Seal Pin
P013	CO2 Puncture Pin
P01301	CO2 Puncture Pin Body
P01302	Rubber Seal
P014	Ball Detent
P01401	Ball Detent Body
P01402	Ball Detent Spring
P01403	Steel Ball
P015	Washer
P01501	Washer
P016	Striker Spring Tension Guide
P01601	ZEUS Striker Spring Tension Guide
P017	ZEUS Cocking Handle
P018	Bolt / Striker Connection Rod
P01801	ZEUS Connection Rod

P019	Quick Strip Pin
P01901	ZEUS Quick Strip Pin
P020	Bolt
P02001	ZEUS Bolt
P021	Striker Rear Cap
P02101	ZEUS Striker Rear Cap
P022	Velocity Adjuster
P02201	ZEUS Velocity Adjuster
P023	Valve Copper Retainer Screw
P02301	Valve Copper Retainer Screw
P024	Copper Retainer Cover
P02401	ZEUS Upside Cover
P02402	ZEUS BL Cover
P025	Co2 Volumes Housing
P02501	For ZEUS
P026	Cup Seal Guide
P02601	For ZEUS
A03	ASM
A0301	ASM Body
A0302	ASM GRIP
A0303	SEAR
A0304	Single Trigger
A0305	Safe Pin
A0306	Steel Ball
A0307	Single Trigger Guard
A0308	Trigger Back
A04	ZEUS MAG
A0401	MAG Body
A0402	MAG Front Cap
A0403	Ball Pusher
A0404	Ball Pusher Pin
A0405	ZEUS Quick Load Plug
A0406	Plug –pull ring
A07	ZEUS CO2 Plug
A0701	Plug Body
A0702	Tightening Pin
A0703	Tightening Pin Screw