


- | | |
|------------------------------|-------------------------------------|
| 1. Hammer Spring Housing | 20. Sight Screw |
| 2. Hammer Spring | 21. Back Sight |
| 3. Hammer | 22. Barrel & Magazine Housing |
| 4. Valve Brass Nut | 23. Front Sight |
| 5. VBN Nylon Washer Seal | 24. Magazine Cap |
| 6. Valve Stem | 25. Set Screws |
| 7. Valve Spring | 26. Pump |
| 8. Valve Steel Washer | 26a. Deluxe Pump (not Pictured) |
| 9. Valve Stem O'ring Seal | 27. Short Pump Screw |
| 10. Valve Body O'ring Seal | 28. Long Pump Screw |
| 11. Valve Body | 29. Hammer Spring Housing Set Screw |
| 12. Valve Body Oring Seal | 30. Short Grip Frame Screw |
| 13. Bolt Spring | 31. Long Grip Frame Screw |
| 14. Bolt | 32. Hand Grip |
| 15. Bolt O'ring Seal | 33. Hand Grip Screw |
| 16. Co2 Cap | 34. Grip Frame |
| 17. Co2 Cap O'ring Seal | 35. Rifle Stock |
| 18. Co2 Puncture Pin Housing | |
| 19. Co2 PPH Oring Seal | |
| 19a. Puncture Pin Housing | |



V1 V2 V3 V4 V5 V6 V7

V8

Valve assembly

V1 Brass Nut
 V2 Brass Nut Seal
 V3 Valve Stem
 V4 Valve Spring

V5 Valve O'ring Seal
 V6 Steel Washer
 V7 Valve Body
 V8 Valve Body O'ring Seal