


Sprint Trigger Frame



NEW ITEM #	NAME OF PARTS
JE1250	SPRINT TRIGGER FRAME (SILVER)
JE1251	SPRINT TRIGGER FRAME (RED)
JE1252	SPRINT TRIGGER FRAME (BLUE)
JE1253	SPRINT TRIGGER FRAME (BLACK)
JE1254	SPRINT TRIGGER FRAME (GREEN)
JE31D	TRIGGER ADJUST SCREW
JE31E	TRIGGER SPRING
JE31C	TRIGGER
E33A	ON/OFF SWITCH
E33	ON/OFF SCREW (M2X6)
JE27	TOUCH SWITCH
JE12	SEAL
JE18D	COIL SET SCREW (1/8") (PC 3.5X11)
JE31E	SEAR SPRING
JE18A	COIL SET

JE29A	CIRCUIT BOARD SCREW (PC 3.5X7)
JE26	CHARGE PIN
JE34C	RECHARGEABLE BATTERY
E30	LED LIGHT INDICATOR
JE30B	LOCK SWITCH
JE32A	SPRINT GRIP COVER
JE16	TRIGGER FRAME SCREW (M5X13)
JE33D	GRIP COVER SCREW (M3X8)
49B	SECONDARY ROLL PIN
49C	TOUCH SWITCH ROLL PIN (PC 2.4mm)
JE18A	SPRINT STRIKER BOLT
19A	SPRINT STRIKER BOLT O-RING
33F	NUT SCREW INSERT